

# Coinco Four Tube Coin Changer

## Model Number

A label indicating the changer's model number and serial number can be found on the side of the coin changer. The model number indicates the country, currency, interface type and payout configuration of the coin changer.

The first three letters of the model number indicate the Country Banking Code (USD=United States/Dollar). The fourth letter indicates the changer model (G = MDB, S = Single Price, L = Logic). The first digit of the model number indicates the series of changer (7 = 700), and the last two digits represent the changer's payout configuration.

<u>Payout Configuration</u>	<u>Tube Location</u>			
	A	B	C	D
01	\$1.00	.10	.05	.25
02	.25	.10	.05	.25
03	\$1.00	.10	.05	\$1.00
04	.25	.25	.25	.25
05	\$1.00	.25	.25	\$1.00
06	.05	.10	.10	.05
07	.05	.10	.10	.10
08	.25	.10	.10	.05
09	.25	.05	.05	.25
10	.05	.05	.05	.05
11	\$1.00	.10	.10	.05
12	.25	.10	.05	.05
13	.25	.05	.25	.25
14	\$1.00	.05	.05	.25
15	.05	.10	.05	.05
16	\$1.00	.25	.25	.25
17	\$1.00	.10	.10	.25
18	\$1.00	.10	.05	.05

Example: USD-G706 = United States Dollar, MDB 700 series, 5-10-10-5 payout

NOTE: "L" model changers should only be configured as 701, 702, or 708.

## Coin Tube Capacity

	<u>5¢ Tube</u>	<u>10¢ Tube</u>	<u>25¢ Tube</u>	<u>\$1.00 Tube</u>
Low Sensor Level	8	11	9	7
Full Sensor Level	78	115	87	74
Hand Load Level	85	123	94	81

